

## **Assigning Samples to Pads**

### **On Axiom Air 25**

1. Press "EDIT" button
2. When screen flashes "Edit Select", hit PAD LEARN key (lowest C note).
3. When screen flashes "Learn", hit the sample you want to place on the pad. The screen should display a note value (C2).
4. Hit the pad you want as the destination. That pad should now play the sample.

### **On the Axiom 25**

1. Press "EDIT" button
2. Hit Data 1 key (lowest F#)
3. Hit the pad you want to use as the destination.
4. Hit the patch up/down arrows as you hit the pad to find the right sample.
5. Hit the enter key (highest C)